



Indicator Lights

LED Color	Mode/Indication
Red	Fast Charge
Green	Trickle charge
Orange	Idle; No connection; Initialization of charge
Green with orange flash	Topping off charge
Orange with green flash	Battery fault
Red Flashing	Charger fault



Single station chargers can be removed from the Multi-Charger System and used independently. Using a Single Station Charger independently requires purchase of the optional charger cord.

Ordering Information

Ordering information		
Description	Part Number	
Five-Unit Power Station; US Cord	811-0801-01	
Five-Unit Power Station; Euro Cord	811-0801-02	
Five-Unit Power Station; UK Cord	811-0801-03	
Five-Unit Power Station; No Cord	811-0801-04	
Single Station Charger; US Cord	811-0802-01	
Single Station Charger; Euro Cord	811-0802-02	
Single Station Charger; UK Cord	811-0802-03	
Single Station Charger; No Cord	298-0013-01	
Optional Single Station Charger Cord; Euro Plug	297-0007-01	
Optional Single Station Charger Cord; US Plug	297-0006-01	
Optional Single Station Charger Cord; UK Plug	297-0008-01	