

## Instruction: GilAir Plus Impinger Mounting

For Impinger bracket kits 811-0921-01-R and 811-0921-02-R



Kit No	For Impinger Holder*	
811-0921-01-R	200222	Single Impinger
811-0921-02-R	200131	Dual Impinger

\* Holders sold separately.

Kits contain:

- 1) Mounting bracket
- 2) 2 ea long screws
- 3) 2 ea short screws
- 4) 4 ea flat washers
- 5) 2 ea hex nuts

Procedure:

- 1) At the rear side of the pump, remove the two case screws on the right side of the belt clip.
- 2) Align the mounting bracket with the case holes and insert the two long screws with flat washers. Do not over tighten.
- 3) Attach the impinger holder (sold separately) using the short screws, flat washers and hex nuts. (See photos).