USB Powered Battery Charger for Sensidyne Air Sampling Products

This manual replaces the charger specific sections of the GilAir BDX-II, GilAir 3, GilAir 5, LFS-113, Gilibrator-2 and Gilibrator Operator's Manuals. Please refer to your operator's manual for Copyright, Trademark, License and Proprietary notices.

Operational Summary:

The charger provides a constant current charge. Charge time is 15 hours and a trickle charge follows to keep the battery pack at top charge indefinitely.

When power is applied a sequence of flashes will detail the charger type.

While connected to USB power, the indicator shows a brief red flash every two seconds as it looks for a battery to be connected. When the charger is plugged into a battery or pump, the red indicator becomes continuous and charge is provided for 15 hours to completely charge the battery. After the charge cycle is complete the indicator changes to continuous green and a trickle current is provided indefinitely.

When the charger detects the battery has been disconnected, it returns to waiting for a battery to be connected. If the battery is disconnected or power removed, the charger will restart the charge when reconnected or repowered.

Power Requirements:

The charger receives power from a USB charging port through a micro B connector. The standard USB charging port can supply 500mA which is sufficient for all charging modes.

Sensidyne supplies an AC Adapter that provides proper power to the charger. Other power supplies, computer USB power, or cell phone chargers may be utilized if they supply the necessary 500mA needed to power the charger.

If insufficient power is available from the power source, charging will stop and there will be a fast flashing red indicator.

Charger Status Indications:

Indicator	Description
Brief red flash	Powered, waiting for battery to be
at 2 sec interval	attached
Fast red flash	Error (Low supply voltage or shorted
off/on	battery)
once per sec	
Continuous red	Charging
Continuous green	Charge complete, trickle charge rate

Model Information:

Part Number	Current	Timing	Connector	Supported Products
615-0601-01-R	194mA	Timed 15 hr	3-Pin	BDX-II
615-9904-01-R	194mA	Timed 15 hr	3-Pin	GilAir 3, GilAir 5, HFS-513
615-0302-01-R	64mA	Timed 15 hr	2.5 Barrel	LFS-113
615-0501-01-R	194mA	Timed 15 hr	2.1 Barrel	Gilibrator-2
615-0502-01-R	64mA	Continu- ous	2.5 Barrel	Gilibrator

Parts List:

Part Number	Description		
811-0601-01-R	Replacement USB Charger, BDX-II		
811-9922-01-R	Replacement USB Charger,		
	GilAir 3 & GilAir 5		
811-0303-01-R	Replacement USB Charger,		
	LFS-113		
811-0504-01-R	Replacement USB Charger,		
	Gilibrator-2		
811-0505-01-R	Replacement USB Charger,		
	Gilibrator		
911-0601-US-R	USB Charger w/AC Adapter,		
911-0001-03-K	US Cord, BDX-II		
911-0601-EU-R	USB Charger w/AC Adapter,		
311 0001 LO N	Euro Cord, BDX-II		
911-0601-UK-R	USB Charger w/AC Adapter,		
JII OOOI OK K	UK Cord, BDX-II		
911-9901-US-R	USB Charger w/AC Adapter,		
	US Cord, Gilair 3 & GilAir 5		
911-9901-EU-R	USB Charger w/AC Adapter,		
	Euro Cord, Gilair 3 & GilAir 5		
911-9901-UK-R	USB Charger w/AC Adapter,		
	UK Cord, Gilair 3 & GilAir 5		
911-0301-US-R	USB Charger w/AC Adapter,		
	US Cord, LFS-113		
911-0301-EU-R	USB Charger w/AC Adapter,		
	Euro Cord, LFS-113		
911-0301-UK-R	USB Charger w/AC Adapter,		
044 0504 110 0	UK Cord, LFS-113		
911-0501-US-R	USB Charger w/AC Adapter,		
911-0501-EU-R	US Cord, Gilibrator-2		
311-0301-EO-K	USB Charger w/AC Adapter, Euro Cord, Gilibrator-2		
911-0501-UK-R	USB Charger w/AC Adapter,		
311 0301 OK K	UK Cord, Gilibrator-2		
911-0502-US-R	USB Charger w/AC Adapter,		
	US Cord, Gilibrator		
911-0502-EU-R	USB Charger w/AC Adapter,		
	Euro Cord, Gilibrator		
911-0502-UK-R	USB Charger w/AC Adapter,		
	UK Cord, Gilibrator		
200 0024 24 2	AC A de sta s		
298-0031-01-R	AC Adapter		
811-9923-US-R	AC Adapter, US Cord		
811-9923-EU-R	AC Adapter, Euro Cord		
811-9923-UK-R	AC Adapter, UK Cord		

USB powered Battery Charger

All components assembled: (Part numbers shown: USB BDXII Charger 615-0601-01-R & AC Adapter w/ US Cord 811-9923-US-R)



Gilian®





USB powered Battery Charger

For Reference:
USB Charger to BDXII Pump installation
(BDXII Pump Sold Separately)





1000 112th Circle N, Suite 100 St. Petersburg, FL 33716 USA (800) 451-9444 • +1 (727) 530-3602 www.Sensidyne.com info@Sensidyne.com

Operation Manual



1000 112th Circle N, Suite 100 St. Petersburg, FL 33716 U.S.A. (800) 451-9444 • +1 (727) 530-3602 www.Sensidyne.com • <u>info@Sensidyne.com</u> REF 360-0178-01 (Rev D)